

10' x 10' FRAME CANOPY

Broadway Party & Tent Rental

www.BroadwayPartyRental.com

IMPORTANT At least 48 business hours BEFORE staking, Customer must call Gopher One (811) to have underground utilities located. Gopher One requests that YOU mark the area of where the tent is going (with white paint) PRIOR to their arrival. Set up Tent with at least an 8' clearance from trees & power lines.


PARTS INCLUDED

- 1 Spider (Ring with 4 attached Poles)
- 4 - 7' Legs
- 4 Corner Castings
- 1 Canopy Top
- 4 - 10' Perimeter Poles
- 4 Ropes/Straps & 4 Stakes


CUSTOMER NEEDS TO PROVIDE 5/8" Wrench & Sledge Hammer

ASSEMBLY


1. Layout Spider, peak up, placing flat on the ground.




2. Layout Perimeter Poles around Spider to form a square. Corners are located at Spider poles.




3. Attach Corner Castings to Spider Poles, center slot is for Spider Poles, put short pin in top hole



4. Put Perimeter Pole into slots on Corner Castings. Tighten nut on Casting using 5/8" wrench (YOU must provide).




5. Layout Canopy Top flat with clips underneath (on bottom) over assembled frame, with corners of Canopy over Corner Castings. The corner holes on Canopy Top go over eye bolts on Corner Castings.




"We Rent Celebrations!"
IF EQUIPMENT IS WORKING INCORRECTLY,
CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE.


6. Layout 1 Leg at each corner. Pick up one side of tent & put Legs in the bottom of Corner Castings, insert a long pin through hole in Leg




7. Pick up other side & insert other Legs into their Corner Castings




8. Attach straps around Perimeter Poles. Put strap behind Perimeter Pole & up through buckle



9. Attach Rope to frame



10. Pound Stakes into ground STRAIGHT UP & DOWN (NOT at an angle) (recommend 4' to 6' from each Corner), leaving about 8" of Stake exposed & tie Rope to Stake & tighten



TO DISASSEMBLE Follow instructions in reverse – PLEASE KEEP SPIDER (Ring & 4 attached Poles) TOGETHER!

“We Rent Celebrations!”
IF EQUIPMENT IS WORKING INCORRECTLY,
CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE.