

**CHAFER**  
**Broadway Party & Tent Rental**  
**763-424-9155**  
www.BroadwayPartyRental.com

**FULLSIZE CHAFER PARTS (STAINLESS STEEL):**

1 – Chafer Frame, 1 Water Pan, 1 Lid, 2 Sterno Holders, 2 Sterno Lids

**HALFSIZE CHAFER PARTS (STAINLESS STEEL):**

One ½ size Chafer Frame, One ½ size Water Pan, One ½ size Lid, One Sterno Holder & Lid

**OPTIONAL ADDITIONAL PIECES:**

Full and ½ size Food Pans, Extra Sterno

**OPERATING INSTRUCTIONS:**

- 1.** Fill water pan with 1” to 1½” of hot water. Check water pan when in use to insure sufficient water is contained at all times.
- 2.** Never light burner unit before putting liquid into water pan. Low flame is sufficient to maintain proper heat.
- 3.** The Food Pans are stainless steel and can be used for cooking in an oven if needed.
- 4.** Do not put unit on a hot stove or over an open flame, besides the sterno flame.

**USE OF STERNO:** Only use sterno for keeping pre-cooked food hot. Pry the cap off sterno container and set into Sterno Holder. Light sterno and adjust Lid for Sterno Holder approximately half open. One can of sterno lasts up to 2 hours.

*Please return clean to avoid a \$10 cleaning charge!*

**CLEANING INSTRUCTIONS:** Return Chafer and Food Pans clean to avoid cleaning charges. Wash in lukewarm water with a mild detergent. Please do NOT use a harsh abrasive!

“We Rent Celebrations!”  
IF EQUIPMENT IS WORKING INCORRECTLY,  
CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE.