

Circulation Fan (Barrel, Drum, Pedestal, Tent)

Broadway Party & Tent Rental

www.BroadwayPartyRental.com

Just having a fan blowing doesn't necessarily mean you get the best airflow & circulation. Fans can be used for both cooling & heat circulation. Fans also help detract bugs outdoors. Here's a few tips to help you keep your cool & improve your airflow situation!

- Setting a single fan in a corner is best to cover more area evenly
- Remove obstacles that may block air flow
- Getting air circulating in a large area can be a chore too great for 1 fan. If you have 2 fans working together, you'll be surprised at how much quicker the temperature drops. Don't be afraid to get more than 1 fan!
 - A 2-fan method is to place one near a window facing out with another in a doorway, effectively creating a wind tunnel. You can also set a fan in diagonal corners across from another, facing the center of the room, & get them to cross circulate. This effect is much like stirring an icy pitcher of lemonade & gets a circular airflow going.
- In larger areas where you want multiple fans continue to place them alternating diagonally (every other opposing side)

GENERAL SAFETY INFORMATION

WARNING - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK *Do not expose fan to water or rain!*

- This fan is intended for general use only
- Do not use near hazardous or explosive materials or vapors
- Never insert fingers or any other objects through the guards when fan is in operation
- Never operate fan without guards in place
- These units are designed to be intrinsically safe, however, never allow children near fan when in operation
- Fan must be located in an area that allows for adequate air flow around the fan
- Barrel & Pedestal Fans must be on stable, flat surface when in operation to avoid possible overturning
- Starving the fan of air may cause the motor to overheat and trigger the unit to shut off
- Barrel & Pedestal Fans must be at least 4 feet from wall or other obstructions
- Unplug the fan before moving from one location to another

POLE MOUNTED TENT FANS: Do NOT mount fan at an angle greater than 45 degrees (as shown). The motor bearings are not suitable for operation beyond this angle. We recommend Tent Fans be installed at least 5 feet from the ground & using 1 every 15-20 feet. We also rent multi-plug extension cords.

ALL FAN Operation:

1. Locate fan in desired location
2. Connect the power cord
3. Turn fan on using power on off switch located on power cord



POLE MOUNTED TENT FAN

“We Rent Celebrations!”

IF EQUIPMENT IS WORKING INCORRECTLY,

CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE 763-208-1357

www.BroadwayPartyRental.com