

# HILAND PATIO FLAME HEATER

Broadway Party & Tent Rental

763-424-6155

www.BroadwayPartyRental.com

**REQUIRES:** 1 - 20 pound Propane Tank which will run approximately 8-10 hours depending on temperature. Heats up to 10' for approximately 8-10 hours. Propane Cylinders are available for rent. If Customer supplies their own Propane it MUST BE a 20 pound Tank & no Service Call will be available.

## **WARNING:**

- Never use Heater while it's raining. The glass tube can break when it comes in sudden contact with water.
- Always turn off Heater while it is raining or drizzling.
- Never splash any liquid at glass tube while heater is working.
- The glass tube will be extremely hot when it's working. Never try to touch it & keep children away from Heater.
- Always ensure the Heater stands firm. The glass tube may break if Heater falls over.
- Never use Heater if glass tube has any cracks.
- Keep a 16" clearance away from heater!

## **LIGHTING INSTRUCTIONS:**

Check & ensure an AA battery is inside ignition chamber & has power. Make sure the Anode (+) faces outside.

1. Ensure the control knob is OFF. Slowly open gas cylinder valve.
2. Press & turn control knob to PILOT position & hold in for 1 full minute.
3. Push the igniter to generate spark while keeping control knob in pressed position.
4. Check for pilot flame through glass tube. If pilot does not light, turn control knob to 'OFF' position, wait a minimum of 2 minutes & try again from step 2. Some attempts maybe necessary.
5. If the pilot lights, keep control knob pressed for 30 seconds longer, then turn control knob to 'LOW'.
6. For maximum heat, turn control knob to 'HIGH'.
7. To turn Heater off, turn control knob to 'OFF'.
8. Close the valve of the gas LP cylinder or the regulator after use.

## **IMPORTANT NOTES:**

**IT'S IMPORTANT TO KEEP 16" CLEARANCE AWAY FROM HEATER!**

*Some City Ordinances require a Permit for EACH Heater &/or Propane Tank.  
Customer is responsible to contact the City of your event & arrange all permitting requirements.*

- 87.5" high
- Floor diameter: 19" x 19" x 36"
- 35,000 BTUs
- 10 ft. heating range diameter
- Wheels included
- Safety anti-tilt switch included

“We Rent Celebrations!”

**IF EQUIPMENT IS WORKING INCORRECTLY,  
PLEASE CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE.**