

SOUND SYSTEM (LONG RANGE)

Broadway Party & Tent Rental

763-424-6155

www.BroadwayPartyRental.com

MASTER UNIT HAS TWO SPEAKERS: ONE HAS AMP, MP3 PLAYER, & BUILT IN WIRELESS RECIEVER, THE OTHER IS A SLAVE UNIT (SPEAKER ONLY)

SET UP:

1. LOSSEN CLAMPS ON STAND LEGS & SPREAD TO DESIRED STANCE THEN RE-TIGHTEN.
2. LOCATE STAND HOLE ON BOTTOM OF SPEAKER UNIT. PLACE SPEAKER ONTO STAND.
3. RAISE OR LOWER UNIT USING CLAMPS ON STAND.
4. USING SUPPLIED CORD CONNECT UNITS TOGETHER. ONE END PLUGS INTO UNSWITCHED SPEAKER OUT ON THE MASTER UNIT, THE OTHER PLUGS INTO SPEAKER INPUT ON SLAVE UNIT.
5. IF POWER SUPPLY'S AVAILABLE, PLUG INTO OUTLET USING SUPPLIED CORD; OTHERWISE UNIT HAS A 4-6 HOUR INTERNAL BATTERY.
6. TURN ON UNIT.
7. TURN ON WIRELESS MICROPHONE.
8. ADJUST MICROPHONE VOLUME & TEST MICROPHONE.
9. IPod/MP3 PLAYER VOLUME IS INDEPENDENT OF MICROPHONE VOLUME.
10. MAKE SURE MIC CHANNEL & CHANNEL ON SOUND SYSTEM MATCH & REMAIN THE SAME.

“We Rent Celebrations!”

**IF EQUIPMENT IS WORKING INCORRECTLY,
CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE.**