

THERMOVATS

Broadway Party & Tent Rental

763-424-6155

www.BroadwayPartyRental.com

Thermo Vats are completely insulated containers for holding, transporting and serving hot or cold beverages. We do not recommend using them to serve water (unless water is used to make a flavored beverage – tea, cocoa, etc).

Heat gain/loss averages 2.5 to 4.5 degrees per hour in a gradual incline/decline respectively.

LOADING FOR MAXIMUM TEMPERATURE MAINTENANCE:

Preheating the unit is not necessary in most cases. If preheating is desired, simply fill with hot water & drain, then refill with beverage.

- Preheat with hot water only
- Fill container to maximum capacity
- Be sure lid gasket is in place before closing container
- Close container as rapidly as possible

CAUTION: If an immersion heater is used to keep beverage hot, **DO NOT** let the hot element come in direct contact with the plastic liner.

Return clean to avoid a Cleaning Charge!

CLEANING INSTRUCTIONS: Special supplies or cleaning equipment are not necessary. Hand clean with regular soap & detergents, fill & flush with clean water (handle in lock – open position). Avoid strong detergent & use a soft cloth.

DO NOT:

- **Use scouring pads or any type of abrasive for cleaning**
- **Immerse the base in water**
- **Clean with a steam cleaner**
- **Wash in dishwasher**

“We Rent Celebrations!”

**IF EQUIPMENT IS WORKING INCORRECTLY,
CONTACT BROADWAY PARTY & TENT RENTAL AS SOON AS POSSIBLE**